

INSTALLATION	Accessory CROSS BARS	Application	Publications No. All 13268
INSTRUCTIONS	P/N 08L04-TK8-100	2013 ODYSSEY	Issue Date AUG 2012
PARTS LIST	IN	STALLATION	
Front cross bar		OTE: The weight of the cargo must no weight capacity of 75 kg (165 lb Be extremely careful not to dam finished surfaces of the body we bars.	os). hage the roof and other
Rear cross bar	L In 1.	stalling the Cross Bars Remove the eight plastic scre and right side roof rails. 8 PLASTIC SCREWS	ews from the left side,
8 Bolts		RIGHT SIDE ROOF RAIL	
TOOLS AND SUPPLIES REQUIRED T-30 Torx driver			
Illustration of the Cross Bars on the Vehicle			FRONT
FRONT CROSS BAR	REAR CROSS BAR	LEFT S ROOF	

 Install the front cross bar to the left side and right side roof rails with four bolts. Torgue the bolts to: 10 N·m (7.3 lbf·ft)



 Install the rear cross bar to the left side and right side roof rails with four bolts. Torque the bolts to: 10 N·m (7.3 lbf·ft)



USE AND CARE

- Check the roof rail mounting bolts frequently, and re-tighten if necessary.
- Distribute the weight of the cargo evenly, and do not exceed the maximum weight capacity of 75 kg (165 lbs).